


| You are in: [Lozier Products](#) > [Products](#) > [Wall End Positioner](#)

Wall End Positioner

Part Number: **Part Number: WEDPOS**



Wall End Positioner maintains the position of your End Display, keeping it from moving by wayward shopping carts or floor scrubbers.

Product Details:

- Attaches freestanding WED or CED to Gondolas of same height or taller
- Maintains End Display position
- Restricts movement from shopping carts or floor scrubbers
- For use on End Displays with acceptable freestanding height-to-depth ratio only

Product Options and Numbers

Example Part #: **WEDPOS** **PLT**

Wall End Positioner: **WEDPOS**

Standard Finish: **PLT**, Optional Catalog Colors

Suffix Key

PLT

- Platinum